

# TRUE WIRELESS EARBUDS

Model: MOTO BUDS 500 ANC



Quick Start Guide

## 1. At a glance




Fig. 1a



Microphones

- 2. Replaceable earcaps (size M)
- 3. Earbud charging contacts
- 4. Multi-function buttons (MFB)
- 5. Microphone
- 6 Charging case
- 7. USB-C charging socket
- 8. Battery level and charging status indicator 10. Charging case charging contact
- 9 Pair/reset button

### 2. Charge



Fig. 2a

Remove all the tapes on the earbuds before charging.



Fig. 2b



Fig. 2c

Plug the Type C cable into the USB-C charging socket of the charging case. The LED indicator flashes blue during charging the battery. It turns solid blue when charging is complete.


When you put the earbuds in the charging case, you will see one of the following scenarios:

LED status	Charging case closed	Charging case opened
Pulses blue	Earbuds are charging	-
Turns solid orange for 4s	Earbuds are fully charged	The battery level of earbuds > 95%
Pulses orange for 18s	The battery capacity is too low to charge the earbuds	-
Turns solid blue for 4s	-	The battery capacity is sufficient to fully charge the earbuds
Flashes blue for 4s	-	The battery capacity is not sufficient to fully charge the earbuds

## 3. On/Off/Pair

- Turn on earbuds: Open the charging case top lid, the earbuds will turn on automatically.
- Turn off earbuds: Put the earbuds into the charging case and close the top lid, the earbuds will be off automatically.

3. Pairing: MOTO BUDS 500 supports Google fast pairing. Open the charging case top lid. For Motorola smartphone or Android phone with Android version 6.0 or above, simply confirm MOTO BUDS 500 directly on your device screen. For other devices, select MOTO BUDS 500 from the Bluetooth menu of your device. When pairing is successful, you will find a notification on your phone and hear a connected tone on the earbuds



### 4. Fit and comfort

- Choose the suitable earcap size.
- Fit into the earbuds



Fig. 4a

3. Insert the earbuds into ears and rotate to fit comfortably.



## 5. Operation

Call	Button
Answer/End a call	Left/right MFB: Tap once
Reject a call	Left/right MFB: Press and hold for 2 seconds
3-way call	
Pick up a call and put the current call on hold/switch calls	Left/right MFB: Tap once
Reject a call and continue the current call	Left/right MFB: Press and hold for 2 seconds
End the current call and resume the on hold call/Pick up a call and end the current call	Left/right MFB: Tap twice
Music	
Play/Pause	Left/right MFB: Tap once
Previous track	Right MFB: Tap 3 times
Next track	Right MFB: Tap twice
Activate voice assistant	
	Right MFB: Press and hold for 2 seconds
Siri, Google	*Need to enable the corresponding voice assistant features on your smartphone.
Noise cancelling on/ Ambient sound/Off	Left MFB: Tap twice
Eastery reset	*

#### Factory reset

- Put both earbuds into the charging case.
- 2. In standby mode, press and hold the reset button for 10 seconds
- The orange LED flashes fast for 10 seconds and the factory reset is done.
- Follow pairing instructions in section 3 to do pairing again.

### 6. Alert sounds


The earbuds play an alert sound when performing the following functions:

- · Ready for pairing
- Ambient sound on
- Active noise cancelling on / off
- Connected to Bluetooth
- Powering off the earbuds
- Low battery level
- · Rejecting an incoming call while on another call
- Receiving an incoming call

For a full explanation of all features and instructions, please download the user guide from motorolasound. com.

### 7. Important notes

 The multi-function button (MFB) of your earbuds has touch sensors that enable different functions.



Avoid touching the MFB when taking out the earbuds.



When inserting the earbuds into ears, hold the sticks and avoid touching the MFB.



#### Technical information

- Frequency band: 2.402 to 2.480GHz
- RF transmission power: < 10dBm (for CE only)</li>
- Working temperature: 0°C to +45°C
- FCC ID: 2ARRB-MB500, IC:20353-MB500

La operación de este equipo está sujeta a las siguientes dos condiciones:

- es posible que este equipo o dispositivo no cause interferencia periudicial y
- este equipo o dispositivo debe aceptar cualquier interferencia, incluyendo la que pueda causar su operación no deseada.

Manufactured, distributed or sold by Meizhou Guo Wei Electronics Co. LTD., official licensee for this product. MOTOROLA and the Stylized M Logo are trademarks or registered trademarks of Motorola Trademark Holdings, LLC. and are used under license. All other trademarks are the property of their respective owners. © 2024 Motorola Mobility LLC. All rights reserved.

Version 3 (EN EU&NA)

